

## Maintenance: Severe Service 20000 MI or 32000 KM

### Check

Brakes

*Inspect linings/drums and pads/discs*

### Inspect

(E) Air Filter Element

Ball Joint Dust Cover, Lower

Ball Joint Dust Cover, Upper

Ball Joint, Lower

Ball Joint, Upper

Body and Frame

*Inspect nuts and bolts on chassis and body Inspect the nuts and bolts on the chassis and body.*

Brake Drum

Brake Pad

Brake Rotor/Disc

Brake Shoe

Constant Velocity Joint Boot

Drive/Propeller Shaft

*Inspect the vehicles driveshaft boots.*

Steering

*Inspect the vehicles steering wheel, linkage and boots.*

(S) Steering and Suspension

*Inspect ball joints and dust covers, inspect steering linkage*

### Replace

(B) Oil

(S) Oil Filter, Engine

### Rotate

Tires

-----  
(S) = Service Warranty Requirement

(E) = Emission Warranty Requirement

(B) = Both Service and Emission Warranty Requirement